

Track A – Field & Lab Operations:  
*Surface Preparation  
& Tack Coats*

2020 MAPA Spring Training – *Black to Basics*  
Holiday Inn Executive Center – Columbia, MO  
February 27-28, 2020



# Potential Distress – Delamination

Delamination occurs when pieces of asphalt pavement break loose and separate from the rest of the structure.



# Potential Distress – Delamination

- Causes
  - Low surface mat density
  - Water gets beneath surface layer
  - Poor/Inadequate bond allows portions to break loose under traffic



# Potential Distress – Slippage Cracking

Crescent or half-moon shaped cracks generally having two ends pointed in the direction of traffic.




# Potential Distress – Slippage Cracking

- Causes
  - Poor/Inadequate bond between surface and underlying layer
  - Braking or Turning
  - Intersections/stop signs
  - Downhill grades
  - Mailboxes????





# Potential Distress – Structural Cracking

NCAT's engineering analysis of a pavement both with and without one of its layers bonded showed an increase in the tensile stresses beneath the load.



# Potential Distress – Structural Cracking

- Causes
  - Poor/Inadequate bond between layers
  - Multi-layered system now acts as independent layers
  - Fatigue cracking initiates when one layer is unable to withstand the tensile strains it is experiencing



# Surface Preparation

- The performance of an asphalt pavement under traffic is directly related to the condition of the surface on which it was placed.
- Surface can be subgrade, aggregate base, or an existing asphalt or concrete pavement.
- Surface preparation often doesn't get the attention it needs.
- It is easy to cover up problems with a new asphalt layer, but rarely do the problems go away.

# Surface Preparation

Preparing an existing asphalt pavement for an overlay may be as simple as sweeping the surface and spraying a tack coat...



# Surface Preparation

... or it may involve numerous other procedures:  
Patching? Leveling? Milling?



# Surface Preparation

- Fill or seal cracks > 1/8 in wide
- Repair structural distresses
- Milling – removal of distressed layers
- Thoroughly clean the surface



# Surface Preparation

- Milling
  - Remove the high spots from an existing surface.
  - Used to maintain the surface profile, such as in curb and gutter situations.
  - Also used to remove mix related problems.
  - **Avoid scabbing!**
  - **Extra effort sweeping!**



# Surface Preparation

- Sweeping
  - After patching, sealing, and/or milling, the surface **MUST** be properly cleaned.
  - Allowing traffic on milled surface helps clean it
  - Typically, a power broom or street sweeper is used.
  - Any foreign material (dried mud, spilled asphalt, etc.) must be removed to insure a strong bond between layers.
  - Re-Sweeping is recommended immediately prior to placing the tack coat.



# Tack Coat

A thin layer of bituminous material placed between asphalt concrete pavement layers to bond the layers together.



# Tack Coat

- Tack Coat Application

- While the surface is still clean and dry, place the tack coat immediately prior to the overlay
- The tack coat ensures a bond between the existing pavement and the overlay.
- Delamination, slippage cracking and/or structural cracking can occur if a bond is not formed between layers to create a “monolithic” structure

# Tack Coat Materials

- Asphalt Emulsions:
  - Slow Setting: SS-1, SS-1h, CSS-1, CSS-1h
  - Rapid Setting: RS-1, RS-2, CRS-1, CRS-2
  - Polymer-Modified: SS-1hP
  - “NT”: Non-Tracking
  - “TT”: Trackless Tack




# Tack Coat Materials

- Advantages:
  - Application uniformity
  - Numerous choices
  - Contractor familiarity
- Disadvantages:
  - Break & Set times
  - Tracking potential



# Tack Coat Materials

- Depending on the formulation, asphalt emulsions are typically 60-70% asphalt cement and 30-40% water.



# Tack Coat Materials

- Break & Set Times:
  - Formulation???
  - Application Rate
  - Climatic Conditions
    - Sunny vs. Cloudy
    - Daytime vs. Nighttime
    - Air, Surface, Emulsion Temperatures
  - Has it been diluted???



# Tack Coat Materials

- Paving Grade Asphalt:
  - No Break or Set times
  - Cool weather/Nighttime paving
  - Excellent performance
  - **Elevated storage and application temperature increases safety risk!!!**



# Tack Coat Application



*“Looking Good!!!”*


- Nozzles must be appropriate size, clean and adjusted
- Height of spray bar and pressure will effect coverage



*“Not Good!!!”*


# Tack Coat Application

## Spray Pattern achieving Triple Overlap



## Proper Settings of Nozzles

Nozzle Angle Setting -  $15^{\circ}$  to  $30^{\circ}$



# Tack Coat Application

- This application might have the correct amount of material, but will not have the same “bond strength” evenly across the interface between layers.
- *No “Corn Rows”!!!*



# Tack Coat Application

- Milled surfaces can be more difficult to plan for, but are still recommended to be tacked.
- Increased texture will require more tack
- *Be sure to clean the surface thoroughly!!!*



# Tack : How much is enough?



# Tack : How much is enough?

- Too much tack is also a bad thing.
- Start with the application rate shown in the project paving plan
- Recommend placing a test strip in accordance with specifications, and adjust based on surface condition
- Even if the calculated rate is correct, the material **MUST** be distributed EVENLY.

# Tack Coat Rate

## FHWA-HIF-16-017: “Tack Coat Best Practices”

Surface Type	Residual Rate (gsy)	Approximate Bar Rate Undiluted* (gsy)	Approximate Bar Rate Diluted 1:1* (gsy)
New Asphalt	0.02 – 0.05	0.03 – 0.07	0.06 – 0.14
Existing Asphalt	0.04 – 0.07	0.06 – 0.11	0.12 – 0.22
Milled Surface	0.04 – 0.08	0.06 – 0.12	0.12 – 0.24
Portland Cement Concrete	0.03 – 0.05	0.05 – 0.08	0.10 – 0.16

\*Assume emulsion is 33% water and 67% asphalt.

# Tack Coat Rate

- Asphalt emulsions are applied brown, and then turn black after they break and set.
- The emulsion should be allowed break and set before placing the surface layer.
- For faster “breaks”, utilize “RS” emulsions, paving grade asphalt, or other specialty products
- Tack coat “residual” rate should not typically need to exceed 0.10 gal/sy.

# Tack Coat Rate

- Example Problem:
  - Initial Reading on Tack Truck: 470 gal
  - Final Reading on Tack Truck: 220 gal
  - Tack applied to 2500' of a 12' wide lane
  - Emulsion: 65% Residual (undiluted)

What's the application rate?

# Tack Coat Rate

Gallons Used = Initial Reading – Final Reading

$$= 470 - 220 = 250 \text{ gallons}$$

$$\text{Coverage (ft}^2\text{)} = 2500' \times 12' = 30,000 \text{ ft}^2$$

$$\text{Coverage (yd}^2\text{)} = 30,000/9 = 3333.3 \text{ yd}^2$$

$$\text{Rate (gal/yd}^2\text{)} = 250/3333 = 0.075 \text{ gal/yd}^2$$

$$\text{Residual Rate} = 0.075 \times 0.65 = \mathbf{0.049 \text{ gal/yd}^2}$$

# So, are tack coats worth the cost?

- Asphalt Institute Investigation
  - Cost of Tack Coats
    - New or Reconstruction: about 0.1 – 0.2% of Total Project Cost
    - Mill & Overlay: about 1.0 – 2.0% of Total Project Cost
  - If Bond Failures Occurred
    - Remedial Action: between 30 – 100% of Original Project Cost



# Resource

- FHWA-HIF-16-017  
“Tack Coat Best Practices”  
April 2016
- <https://www.fhwa.dot.gov/pavement/asphalt/pubs/hif16017.pdf>



# Questions?



Michael H. Huner, P.E.  
Huner Consulting, LLC  
mike@hunerconsulting.com  
(615) 477-5079 CELL